


USER GUIDE TOP CASES

SH47



SH46



SH45



SH42



SH40



SH40 CARGO



ACCESSORIES (OPTIONAL)




Backrest



Colour cover



Brake light Ref. D0B40KL




Inner Bag (SH42, SH45, SH46, SH47)

Find out about other products at


WWW.SHAD.ES

OPEN ASSEMBLY


CLOSE




RELEASE









SH40 Cargo

* Only for SH40 Cargo

#	Piece	Quantity
1	Clip	4
2	Screew	4
3	Washer	4









TOP CASE SUPPORT ASSEMBLY

Use top case parts

#	Piece	Quantity
1	Clip	4
2	Screw M6x40	4
3	Plastic spacer	4
4	Ø6 Washer M6	4
5	Nut M6	4
6	Screw M6x30	4








Use fitting kit parts

#	Piece	Quantity
7	Metal spacer	4
8	Screw M8x20	4
9	Washer M8	4
10	Nut M8	4




CHECK BIKE COMPATIBILITY

WWW.SHAD.ES *



SHAD Top Master*



SHAD Top Master*

CARE AND MAINTENANCE



1 M. MINIMUM DISTANCE WITH POWER WASHER.



MAXIMUM WEIGHT. (SH42, SH45, SH46, SH47)



MAXIMUM WEIGHT. (SH40, SH40 Cargo)



ALWAYS SECURE AND LOCK PRODUCTS.



CASES ARE NOT DESIGNED TO PROTECT FRAGILE OBJECTS.



MAXIMUM SPEED, CHECK LOCAL LAWS.



Octave Lecante, 2-6 Pol, Ind. Can Magarola 08100 MOLLET DEL VALLÈS BARCELONA (SPAIN)

Phone: 0034 935 795 860 Fax: 0034 935 796 945 info@shad.es